World eSIM User Guide



Before Traveling:

Visit my.worldmobile.com to Top-up & manage.

Upon Landing Abroad:

- 1. Turn on World eSIM and turn off your Home SIM.
- iPhone: Settings > Cellular > eSIM (located below 'Primary').
- Samsung: Settings > Connections > SIM manager > eSIM
- 2. Activate Data roaming (your WhatsApp will function normally abroad).
- iPhone: Settings > Cellular > eSIM
- Samsung: Settings > Connections > Mobile networks
- Free Dial Services: Top-up & manage: +120 eSIM numbers: +170
- Check balance: +140 Keep your number: +160 Support: +180
- Calling Worldwide:
- Dial from your contacts **OR** + Country code Area (No 0) Tel.
 - *SMS can be received on the +44 number of the World eSIM.

Troubleshooting:

- 1. <u>For Any Issue</u>: <u>Restart your mobile</u>, ensure **World eSIM** is turned on and your Home SIM is turned off & dial +120 to check your balance.
- **2. Locked Phone:** If a PIN or unlock code is requested, contact your mobile carrier to unlock it or use another phone as a Wi-Fi hotspot.
- 3. Calling Issues: Dial: *126* Country-Area (No 0)-Tel.# (answer callback).
- **4. Network Issues:** Manually select another network until connected. iPhone: Settings > Cellular > eSIM > Network Selection > Auto. off Samsung: Sett. > Conn. > Mobile net. > Network oper. > eSIM > Auto. off
- 5. Internet Issues: Ensure Data roaming is ON. If not solved, set APN: iPhone: Settings > Cellular > eSIM > Cellular Data N. > APN: mobiledata Samsung: Settings > Connections > Mobile net. > Access Point Name > eSIM > Add > Name: worldmobile & APN: mobiledata > Save & Select.

For more information visit: www.worldmobile.com/support